

Scrolling

REMOTE CONTROL
LED SIGN BOARD

QUICK REFERENCE
GUIDE



New

QWERTY
Keypad!



www.tvliquidator.com
1-888-885-7740

Static Messages
Scrolling Messages
Multi-line Messages
Quick Tips

TV Liquidator

U.S. Distributor of LED Signs

Create a Scrolling Message

Press the [MENU] button on the top right of the hand-held remote.

You will see it display...

"1. Add MSG" Once you see this, press [ENTER]

Now you will see it display **"1. New MSG"** press [ENTER]

Now you will see it display **"1. Single line"** press [ENTER]

"Input your message" will scroll across the screen followed by a **Blinking Cursor** on the **left side** of the screen, indicating the sign is ready to begin typing a message.

To create a scrolling message

- 1) Type your message across the sign. When done entering your message press [ENTER]
- 2) **"Select a start effect"** will scroll across the screen then **"1.3D"** will appear. Press the **effects down arrow button** to **"3. Manual"** then press [ENTER]
- 3) **"1. Scroll"** will appear, press [ENTER]. You will see half of your message scroll across the screen, **"THIS IS A PREVIEW ONLY"**. If you like the scrolling message effect, press [ENTER] and wait for **"Complete"** to scroll across the screen. You are done.

When **"1. Add MSG"** appears, your message has been saved in the memory and you are back at the beginning. Press [Menu] once to exit and wait to see your message display.

Thank you for visiting TV Liquidator, if you have any questions or need further assistance, call our customer support team at 1-888-885-7740.



Create a 1-line Message STATIC

Press the [MENU] button on the top right of the hand-held remote.

You will see it display...

"1. Add MSG" Once you see this, press [ENTER]

Now you will see it display **"1. New MSG"** press [ENTER]

Now you will see it display **"1. Single line"** press [ENTER]

"Input your message" will scroll across the screen followed by a **Blinking Cursor** on the **left side** of the screen, indicating the sign is ready to begin typing a message.

To create a 1-line Static message

- 1) Type across the sign to the edge. When done entering your message press [ENTER]
- 2) **"Select a start effect"** will scroll across the screen then **"1.3D"** will appear. Press the **effects down arrow button** until you see **"3. Manual"** then press [ENTER]
- 3) **"1. Scroll"** will appear across the screen. Press the **effects down arrow button** to **"7. No Effects"** then press [ENTER]
- 4) **"Select a wait effect"** will scroll across the screen, then **"1. BG Image"** will appear. Press the **effects down arrow button** to **"3. STOP"** then press [ENTER]
- 5) **"Select a wait time"** will scroll across the screen, then **"00:00:00" (HR:MIN:SEC)** will appear. Use the **effect and speed arrow buttons** to change the message hold time, then press [ENTER]
- 6) **"Select an end effect"** will scroll across the screen, then **"1. No Effect"** will appear. Press [ENTER] then wait for **"Complete"** to scroll across the screen. You are done.

When **"1. Add MSG"** appears, your message has been saved in the memory and you are back at the beginning. Press [Menu] once to exit and wait to see your message display.

Thank you for visiting TV Liquidator, if you have any questions or need further assistance, call our customer support team at 1-888-885-7740.



Create a 2-line Message STATIC

Press the [MENU] button on the top right of the hand-held remote.

You will see it display...

"1. Add MSG" Once you see this, press [ENTER]

Now you will see it display **"1. New MSG"** press [ENTER]

Now you will see it display **"1. Single line"** press [ENTER]

"Input your message" will scroll across the screen followed by a **Blinking Cursor** on the **left side** of the screen, indicating the sign is ready to begin typing a message.

To create a 2-line static message

- 1) Press the [FONT SIZE] button above number 8 until you see the cursor shrink to a small blinking cursor half the height of the sign, this will be LINE 1. Type across the sign to the edge then press the **effects down arrow button** to enter LINE 2. When done entering your message press [ENTER]
- 2) **"Select a start effect"** will scroll across the screen then **"1.3D"** will appear. Press the **effects down arrow button** until you see **"3. Manual"** then press [ENTER]
- 3) **"1. Scroll"** will appear across the screen. Press the **effects down arrow button** to **"7. No Effects"** then press [ENTER]
- 4) **"Select a wait effect"** will scroll across the screen, then **"1. BG Image"** will appear. Press the **effects down arrow button** to **"3. STOP"** then press [ENTER]
- 5) **"Select a wait time"** will scroll across the screen, then **"00:00:00" (HR:MIN:SEC)** will appear. Use the **effect and speed arrow buttons** to change the message hold time, then press [ENTER]
- 6) **"Select an end effect"** will scroll across the screen, then **"1. No Effect"** will appear. Press [ENTER] then wait for **"Complete"** to scroll across the screen. You are done.

When **"1. Add MSG"** appears, your message has been saved in the memory and you are back at the beginning. Press [Menu] once to exit and wait to see your message display.

Thank you for visiting TV Liquidator, if you have any questions or need further assistance, call our customer support team at 1-888-885-7740.



Create a 4-line Message STATIC

Press the [MENU] button on the top right of the hand-held remote.

You will see it display...

"1. Add MSG" Once you see this, press [ENTER]

Now you will see it display **"1. New MSG"** press [ENTER]

Now you will see it display **"1. Single line"** press [ENTER]

"Input your message" will scroll across the screen followed by a **Blinking Cursor** on the **left side** of the screen, indicating the sign is ready to begin typing a message.

To create a 4-line static message

- 1) Press the [FONT SIZE] button above number 8 until you see the cursor shrink to a small blinking cursor one-quarter (1/4) the height of the sign, this will be LINE 1. Type across the sign to the edge then press the **effects down arrow button** to enter LINE 2. Repeat for LINE 3 and LINE 4. When done entering your message across the 4 lines press [ENTER]
- 2) **"Select a start effect"** will scroll across the screen then **"1.3D"** will appear. Press the **effects down arrow button** until you see **"3. Manual"** then press [ENTER]
- 3) **"1. Scroll"** will appear across the screen. Press the **effects down arrow button** to **"7. No Effects"** then press [ENTER]
- 4) **"Select a wait effect"** will scroll across the screen, then **"1. BG Image"** will appear. Press the **effects down arrow button** to **"3. STOP"** then press [ENTER]
- 5) **"Select a wait time"** will scroll across the screen, then **"00:00:00" (HR:MIN:SEC)** will appear. Use the **effect and speed arrow buttons** to change the message hold time, then press [ENTER]
- 6) **"Select an end effect"** will scroll across the screen, then **"1. No Effect"** will appear. Press [ENTER] then wait for **"Complete"** to scroll across the screen. You are done.

When **"1. Add MSG"** appears, your message has been saved in the memory and you are back at the beginning. Press [Menu] once to exit and wait to see your message display.

Thank you for visiting TV Liquidator, if you have any questions or need further assistance, call our customer support team at 1-888-885-7740.



TV Liquidator

U.S. Distributor of LED Signs

Programming Tips

TIPS: The LED sign is menu based and very easy to navigate. Simply press [ENTER] to select an option and another menu will become available to you. See page 5 in the instruction manual for a complete menu map. Use the **UP/DOWN effect arrow** buttons to navigate through the menu lists. Use the [ESC] button to back up one level without exiting. At any time, you can press the [MENU] button to exit out of the menu and view saved messages.

Change the font: Get to the “**Input Message**” screen, type out one letter then move the cursor back to the left of the same letter and press the [FONT] button (next to the A button). A flashing square will appear around the letter indicating you can now change the font. Keep pressing the [FONT] button to rotate through the available fonts. Choose your font by pressing the **right speed arrow** key to move the cursor to the right of the letter. Continue typing your message and the font will stay selected until you change it again.

Change the color: Get to the “**Input Message**” screen, type out one letter then move the cursor back to the left of the same letter and press the [COLOR] button (next to the Z button). A flashing square will appear around the letter indicating you can now change the color. Keep pressing the [COLOR] button to rotate through the available colors. Choose your color by pressing the **right speed arrow** key to move the cursor to the right of the letter. Continue typing your message and the color will stay selected until you change it again.

Access orange symbol characters: Press and release the orange [FN] button on the bottom left of the remote, then press the letter with the desired character. Press the [FN] button again to return to the regular white characters.

Change scroll speed: While viewing your live scrolling message, press the **left speed arrow** button and the scrolling speed will decrease. Press the **right speed arrow** button to increase scrolling speed.

Change sign brightness: While viewing your live messages, press the orange [FN] button followed by the **up/down effect arrow** button. You will see a number appear in the center indicating brightness level. Use the **up/down effect arrow** buttons to increase or decrease the brightness level as needed.

Turn off time: [MENU] → 1. Add MSG → 3. Insert Time → 2. Frequency → change frequency to “0m” by using up/down arrows. When done press [MENU] to exit.

Turn off date: [MENU] → 1. Add MSG → 4. Insert Date → 2. Frequency → change frequency to “0m” by using up/down arrows. When done hit [MENU] to exit.

Turn timer on/off: If the sign turns off and on randomly, your timer could be on. Turn it off by pressing [MENU] → 8. User Settings → 1. Timer, then toggle on/off with the **up/down effect arrow** buttons.

Thank you for visiting TV Liquidator, if you have any questions or need further assistance, call our customer support team at 1-888-885-7740.

